



Zweckbestimmung: Funk-Druckknopfsender für Visit System

Zulässige Betriebsbedingung: Für Innen und Außen in geschützter Lage. Verträgt kein Wasser

oder Regen

Nur mit trockenem/ leicht feuchtem Tuch abwischen Reinigungshinweise: Wartungshinweis: Wartungsfrei, Batterien können ausgetauscht werden

Technische Daten: Batterie 6V tvp PX28

Hinweis zum Wiedereinsatz: Das Produkt ist nicht für den Wiedereinsatz für einen andere

Person vorgesehen



For use in all EU countries

Hereby, Bellman & Symfon AB, declares that this BE1420 Push Button Transmitter is in compliance with the essential requirements and other relevant provisions of directives: R&TTE 1999/5/EC, LVD 1973/23/EC, EMC 1989/336/EC, MDD 1993/42/EEC.

Correct use and disposal of batteries:

Replace only with the same or equivalent type recommended by the manufacturer. Please dispose of old, defective batteries in an environmentally friendly manner in accordance with the relevant legislation.

For a complete Declaration of Conformity please contact info@bellman.se or call +46 31 68 28 20



Push button transmitter User manual

bellman.com

For information about this product in other languages, contact support at info@bellman.com

European office

Bellman & Symfon Europe AB Södra Långebergsgatan 30 421 32 Västra Frölunda Sweden

Phone +46 31 68 28 20

Fax +46 31 68 28 90 E-mail info@bellman.com

Asia Pacific office


Bellman & Symfon Asia Ltd. 1115-16, Main Tower, GD Int'l Hotel 339 Huanshi Dong Rd Guangzhou, China, 510095 Phone +86 20 8318 2950 Fax +86 20 8333 5528

E-mail info.cn@bellman.com

© 2013, Bellman & Symfon AB, all rights reserved. Bellman, Bellman & Symfon and the Bellman & Symfon logo are registered trademarks of Bellman & Symfon AB.

bellman.com

1. 2.



3. 4.

